500MM FLOOR FAN OWNERS MANUAL

BE's 500 mm industrial floor fan is designed to provide powerful ventilation and effective cooling in a wide range of environments. It is ideal for use in factories, warehouses, workshops, offices, and other public or commercial spaces, delivering high airflow to improve air circulation and maintain a comfortable working environment.

OPERATING INSTRUCTIONS

A. The voltage and frequency indicated a nameplate must be in compliance with local supply voltage and frequency.
B. Speed control adjustment can be made on the front control panel. 0 is the unit off and speeds 1, 2 and 3 are for low, medium and high.
C. Fan head tilt adjustment: Turn the fan head to the desired angle.

IMPORTANT INSTRUCTIONS

A. Do not block the oscillation of the fan to avoid accidents.
B. Do not hitch the power cord in any manner.
C. If the power cord gets damages, please call the service representative.
D. Unplug from outlet, before removing parts before cleaning. Do not bend the blade to change angle of blade.

MAINTENANCE

When you are finished using the fan, clean then store in a cool dry place.

FUNCTION PARAMETER LIST

Model	Size	Voltage	Frequency	Power	Air Volume	Speed
PIN FF20	500 mm	240 V	50 Hz	180 W	142 m³/min	1600 RPM

AUSTRALIA
BAR Group Pty Ltd
15 Hudson Place, Mulgrave NSW 2756
PH:02 4577 2144

NEW ZEALAND
BE Pressure Supply Ltd
541D Te Rapa Road, Te Rapa, Hamilton 3200
PH: 07 849 0000