

PURE POWER

14" WHIRL-A-WAY

125 BAR1400-PP



USER MANUAL
V1.0 2026

TABLE OF CONTENTS

Introduction

Using the Operator's Manual	3
-----------------------------------	---

Product Identification

Record Identification Numbers	4
-------------------------------------	---

Pre-Operating Instructions

Before You Begin	5
Intended Use	5
Care	5

Operating

Operating	6
Use with a Gun and Lance	6
Attach to Long Wand	6

Parts List

Parts List	6
------------------	---

Troubleshooting and Warranty

Troubleshooting	7
Warranty	7

INTRODUCTION



Attention: Read through the complete manual prior to the initial use of your Whirl-A-Way.

Using the Operator's manual

The operating manual is an important part of your 14" Whirl-a-Way and should be read thoroughly before initial use, and referred to often to make sure adequate safety and service concerns are being addressed. Reading the owner's manual thoroughly will help avoid any personal injury or damage to your Whirl-a-Way. The information in this manual will offer you the most effective tools for cleaning as well as the safest. By knowing how best to operate this machine you will be better positioned to show others who may also operate the unit. You can refer back to the manual at any time to help troubleshoot any specific operating functions, so store it with the machine at all times.

PRODUCT IDENTIFICATION

RECORD IDENTIFICATION NUMBERS

If you need to contact an Authorized Dealer or Customer Service line please call 02 4577 2144 (Australia) or 07 849 0000 (New Zealand) for information on servicing and make sure to always provide the product model and identification numbers.

You will need to locate the model and serial number for the pump and record the information in the places provided below.

Date of Purchase:

Dealer Name:

Dealer Phone:

Product Identification Numbers

Model Number:

Serial Number:

PRE-OPERATING INSTRUCTIONS

BEFORE YOU BEGIN

Prior to initial operation of the unit carefully read the information outlined in the operation instructions.

- Ensure that all components are in good working order and that they operate safely.
- Do not use cleaner if any part is not in proper working condition.
- No modifications permitted on the machine.
- Before operation test the cleaner at low pressure 1,500 PSI to ensure you can operate safely at high pressures.

The surface Cleaning System you have purchased connects directly to a 1/4" quick connect coupler, operating to a maximum of 4,000 PSI.

WARNING

This product uses extreme water pressure and water force. This may cause kickback when using the cleaner.

This 14" Whirl-A-Way is designed to operate with cold water pressure cleaners. We do not recommend the use of hot water as the nylon brush skirt will soften and wear prematurely, voiding any warranty.

Before operation ensure that the pressure cleaner is on low pressure when first using the Whirl-A-Way. Adjust pressure with adjustable unloader.

INTENDED USE

The Whirl-A-Way is suitable for cleaning floors and walls in conjunction with a high pressure cleaner.

(A) Recommend Operating pressure: 2,000-3,600 PSI

(B) Maximum pressure: 4,000 PSI

(C) Maximum water temperature: 85°C/180°F

Never exceed maximum operating pressure and temperature.

CARE

- Protect from frost/freezing.
- Ensure bristles are not deformed during storage.

Please dispose of packaging environmentally responsibly

The packaging materials are recyclable. Please do not throw the packaging in the household rubbish but take it to a recycling centre.

OPERATING



WARNING

Nozzle has been set according to factory set alignment.

- Never reach under the unit while the high-pressure cleaner is operating
- Never direct the 14" Whirl-a-Way at humans or animals.
- Do not operate on a ladder. During operation, should you experience a buildup of small stones or other foreign material within the cover, we recommend that you simply tip the cleaner on its side at 45° which should expel any foreign materials. This will extend the life of your tips and rotary arm. The tips that have been installed on your surface cleaning system permit the use of your cleaner with a pressure washer producing up to 15.1 L/min at 4,000 PSI. This unit will not spin efficiently with flow under 8.7 L/min. Periodically check the tips to ensure they are not plugged by dirt particles. It is very important when operating your 14" Whirl-a-Way, that you maintain a continuous motion.
- Should you leave the cleaner in a stationary position, the surface being cleaned can be seriously damaged by the high pressure.

Connect to lance using q/c fittings on the lance and 14" Whirl-a-Way

ATTACH TO LONG WAND

Attach to a longwand for cleaning hard to reach surfaces. Connect to longwand using the QC fittings on the longwand and 14" Whirl-a-Way.

FOR 15 L/MIN, USE #020 NOZZLE

PARTS LIST



REF	PART #	DESCRIPTION
A	BF5004	Brush Skirt
B	BF5001	Rotary Head
C	BF5002	Rotary Arm

TROUBLESHOOTING

Problem	Cause	Solution
Rotary arm not spinning	▪ 1 or more plugged nozzles ▪ Nozzles not aligned with arm ▪ Damaged nozzle or rotary arm	▪ Clean or replace nozzles ▪ Realign nozzles ▪ Replace damaged part(s)
Leaking water from weep hole	▪ Damaged or worn seals	▪ Replace rotary head
Leaking water from QC plug	▪ Damaged or missing o-ring in coupler	▪ Replace o-ring
Unit vibrating while in use	▪ One or more plugged nozzles ▪ Uneven nozzle ware ▪ Damaged nozzle or rotary arm ▪ Miss matched nozzles	▪ Clean nozzles ▪ Replace damaged part(s) ▪ Replace nozzles

WARRANTY

This surface cleaning unit has a 1 Year warranty on all components except for the nylon brush ring. This includes the rotary head, and plastic cover.

This warranty covers **manufacturer defects only** and does not extend to any damage caused by the user. It also does not extend to any wear and tear caused by regular use of the product.

PURE POWER

If you need assistance with the
assembly or operation of this
Surface Cleaner please call

02 4577 2144