


# MODEL BV 691TR

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number: 12939000937

Rev -- Sep. 2020





# MODEL BV 691TR

UNIT 3

PARTS LIST

N°	CODE	DESCRIPTION
1	4240.826	1 WAY OUTLET
	4240.669	4 WAY OUTLET
2	4240.830	HANDLE
3	4111.057	HANDLE CAP
4	4162.934	BOX COVER HANDLE
5	4240.476	TRANSPARENT CAP
6	4240.842	BURNER BOX COVER
7	4240.772	BURNER BOX CLAMP
8	4240.666	BURNER STABILIZER
9	4240.777	DOCUMENTS HOLDER
10	4614.001	BURNER PLUG
11	4514.304	BURNER
12	4514.168	BURNER METAL PLATE
13	4514.616	BURNER INSULATION PLATE
14	4240.475	RUBBER CAP
15	4240.770	CONTROL BOX BRACKET
16	4031.581	90° CONNECTION
17	4240.843	RIGHT SIDE BURNER PANEL
18	4240.273	CABLE RUBBER PROTECTION
19	4240.484	LOWER BURNER PANEL
20	4240.845	LEFT SIDE BURNER PANEL
21	4240.847	EXTERNAL BURNER PANEL
22	4240.849	INSULATION BURNER PANEL
23	4240.717	WIRE HOOK
24	4117.757	STRAIGHT CONNECTION
25	4240.590	90° CONNECTION
26	4	FUEL FILTER
27	4240.402	FUEL FILTER PANEL
28	4034.378	STRAIGHT CONNECTION
29	4034.257	METAL CAP
30	4240.828	EXTERNAL SIDE PANEL
31	4240.656	INTERNAL SIDE PANEL
32	4240.264	FAN
33	4240.634	INTERNAL INSULATION PANEL
34	4240.647	INTERNAL UPPER BIG PANEL
35	4240.629	EXTERNAL UPPER BIG PANEL
36	4240.646	INTERNAL CHIMNEY PANEL
37	4240.631	EXTERNAL CHIMNEY PANEL
38	4240.436	REGULATION CHIMNEY PANEL
39	4241.092	COMBUSTION CHAMBER
40	4241.085	TURBULIZATOR
41	4240.477	CHIMNEY CAP
42	4240.624	EXTERNAL CHAMBER PANEL
43	4240.621	INSULATION CHAMBER PANEL
44	4240.642	EXTERNAL BACK PANEL
45	4240.639	INTERNAL BACK PANEL
46	4240.505	LIFTING BRACKET
47	4240.191	CHASSIS CORNER
48	4240.605	SMALL HORIZONTAL PROFILE
49	4240.834	FRONT LEFT PROFILE
50	4240.832	FRONT RIGHT PROFILE
51	4240.838	LOWER LEFT PROFILE
52	4240.836	LOWER RIGHT PROFILE
53	4240.613	BACK LEFT PROFILE
54	4240.611	BACK RIGHT PROFILE
55	4240.615	UPPER LEFT PROFILE
56	4240.603	UPPER RIGHT PROFILE
57	4240.742	MOTOR PANEL

# MODEL BV 691TR

UNIT 3

PARTS LIST

N°	CODE	DESCRIPTION
58	4240.732	REINFORCEMENT PROFILE
59	4100.656	NUT
60	4150.528	STRAIN RELIEF
61	4514.607	WIRE PROTECTION
62	4510.855	SENSOR CLIP
63	4240.438	SENSOR BRACKET
64	4240.625	CHAMBER SUPPORTING BEAM
65	4240.660	FOOT
66	4240.637	LOWER BIG PANEL
67	4240.635	LOWER SMALL PANEL
68	4514.845	WHEEL CLIP
69	4241.081	WHEEL
70	4240.773	AXLE BRACKET
71	4241.083	WHEELS AXLE
72	4240.407	BURNER WIRE
73	4160.651	STRAIN RELIEF
74	4160.648	MOBILE COVER
75	4161.401	MALE PLUG
76	4161.400	FEMALE SOCKET
77	4160.647	90° COVER
78	4162.970	THERMOSTAT CAP
79	4240.577	FUSE HOLDER
80	4117.057	FUSE
82	4033.905	LIMIT THERMOSTAT CAP
83	4033.906	LIMIT THERMOSTAT NUT
84	4240.290	LIMIT THERMOSTAT
85	4100.656	NUT
86	4150.528	STRAIN RELIEF
87	4260.288	CAP
88	4240.405	METAL BOX
89	4240.406	TEMPERATURE SENSOR
90	4240.409	COMPONENTS BRACKET
91	4240.414	SWITCH
92	4240.599	BYPASS SWITCH
93	4117.058	LED
94	4510.414	TERMINAL BOX
95	4117.669	MOBILE TERMINAL BOX
96	4240.138	CONTACTOR
97	5247.303	THERMAL RELAY
98	4240.541	HOUR COUNTER GASKET
99	4240.540	ELECTRONIC CONTROLLER GASKET
100	4240.663	ELECTRONIC CONTROLLER
101	4240.416	HOUR COUNTER
102	4240.412	FRONT LABEL
103	4240.700	POWER CORD
104	4514.725	BELT GRILLE
105	4514.726	LATERAL GRILLE
106	4241.050	MOTOR PUPPORT
107	4514.839	MOTOR ADJUSTABLE FOOT
108	4241.051	MOTOR BASE
109	4514.310	MOTOR
110	4241.052	MOTOR CARTER
112	4517.130	MOTOR BELT PULLEY
113	4514.333	MOTOR BELT PULLEY COUPLING
114	4517.133	FAN BELT PULLEY COUPLING
115	4514.340	FAN BELT PULLEY
116	4241.053	BELT CARTER
117	4514.337	BELT
118	4514.414	THREE-PHASE PLUG

# MODEL BV 691TR


UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number: 12939000001

Rev -- Sep. 2019


Until Serial Number: 12939000937



# MODEL BV 691TR

UNIT 2

ILLUSTRATED PARTS BREAKDOWN



# MODEL BV 691TR

UNIT 3

PARTS LIST

N°	CODE	DESCRIPTION
1	4240.826	1 WAY OUTLET
	4240.669	4 WAY OUTLET
2	4240.830	HANDLE
3	4111.057	HANDLE CAP
4	4162.934	BOX COVER HANDLE
5	4240.476	TRANSPARENT CAP
6	4240.842	BURNER BOX COVER
7	4240.772	BURNER BOX CLAMP
8	4240.666	BURNER STABILIZER
9	4240.777	DOCUMENTS HOLDER
10	4614.001	BURNER PLUG
11	4514.30	BURNER
12	4514.168	BURNER METAL PLATE
13	4514.616	BURNER INSULATION PLATE
14	4240.475	RUBBER CAP
15	4240.770	CONTROL BOX BRACKET
16	4031.581	90° CONNECTION
17	4240.843	RIGHT SIDE BURNER PANEL
18	4240.273	CABLE RUBBER PROTECTION
19	4240.484	LOWER BURNER PANEL
20	4240.845	LEFT SIDE BURNER PANEL
21	4240.847	EXTERNAL BURNER PANEL
22	4240.849	INSULATION BURNER PANEL
23	4240.717	WIRE HOOK
24	4117.757	STRAIGHT CONNECTION
25	4240.590	90° CONNECTION
26	4033.090	FUEL FILTER
27	4240.402	FUEL FILTER PANEL
28	4034.378	STRAIGHT CONNECTION
29	4034.257	METAL CAP
30	4240.828	EXTERNAL SIDE PANEL
31	4240.656	INTERNAL SIDE PANEL
32	4240.264	FAN
33	4240.634	INTERNAL INSULATION PANEL
34	4240.647	INTERNAL UPPER BIG PANEL
35	4240.629	EXTERNAL UPPER BIG PANEL
36	4240.646	INTERNAL CHIMNEY PANEL
37	4240.631	EXTERNAL CHIMNEY PANEL
38	4240.436	REGULATION CHIMNEY PANEL
39	4240.622	COMBUSTION CHAMBER
40	4517.786	TURBULIZATOR
41	4240.477	CHIMNEY CAP
42	4240.624	EXTERNAL CHAMBER PANEL
43	42 0.621	INSULATION CHAMBER PANEL
44	4240.642	EXTERNAL BACK PANEL
45	4240.639	INTERNAL BACK PANEL
46	4240.505	LIFTING BRACKET
47	4240.191	CHASSIS CORNER
48	4240.605	SMALL HORIZONTAL PROFILE
49	4240.834	FRONT LEFT PROFILE
50	4240.832	FRONT RIGHT PROFILE
51	4240.838	LOWER LEFT PROFILE
52	4240.836	LOWER RIGHT PROFILE
53	4240.613	BACK LEFT PROFILE
54	4240.611	BACK RIGHT PROFILE
55	4240.615	UPPER LEFT PROFILE
56	4240.603	UPPER RIGHT PROFILE
57	4240.	MOTOR PANEL

# MODEL BV 691TR

UNIT 3

PARTS LIST

N°	CODE	DESCRIPTION
58	4240.	k-@7 k#-U -Vu'hk\ 7@
59	4100.656	NUT
60	4150.528	STRAIN RELIEF
61	4514.607	WIRE PROTECTION
62	4510.855	SENSOR CLIP
63	4240.438	SENSOR BRACKET
64	4240.625	CHAMBER SUPPORTING BEAM
65	4240.660	FOOT
66	4240.637	LOWER BIG PANEL
67	4240.635	LOWER SMALL PANEL
68	4514.845	WHEEL CLIP
69		WHEEL
70	4240.773	AXLE BRACKET
71	4	WHEELS AXLE
72	4240.407	BURNER WIRE
73	4160.651	STRAIN RELIEF
74	4160.648	MOBILE COVER
75	4161.401	MALE PLUG
76	4161.400	FEMALE SOCKET
77	4160.647	90° COVER
78	4162.970	THERMOSTAT CAP
79	4240.577	FUSE HOLDER
80	4117.057	FUSE
81	4240.413	LATERAL LABEL
82	4033.905	LIMIT THERMOSTAT CAP
83	4033.906	LIMIT THERMOSTAT NUT
84	4240.290	LIMIT THERMOSTAT
85	4100.656	NUT
86	4150.528	STRAIN RELIEF
87	4260.288	CAP
88	4240.405	METAL BOX
89	4240.406	TEMPERATURE SENSOR
90	4240.409	COMPONENTS BRACKET
91	4240.414	SWITCH
92	4240.599	BYPASS SWITCH
93	4117.058	LED
94	4510.414	TERMINAL BOX
95	4117.669	MOBILE TERMINAL BOX
96	4240.13	CONTACTOR
97		THERMAL RELAY
98	4240.541	HOUR COUNTER GASKET
99	4240.540	ELECTRONIC CONTROLLER GASKET
100	4240.663	ELECTRONIC CONTROLLER
101	4240.416	HOUR COUNTER
102	4240.412	FRONT LABEL
103	4240.538	POWER CORD
104	4514.725	BELT GRILLE
105	4514.726	LATERAL GRILLE
106	4240.283	MOTOR PUPPORT
107	4514.839	MOTOR ADJUSTABLE FOOT
108	4240.284	MOTOR BASE
109	4514.310	MOTOR
110	4240.286	MOTOR CARTER
111	4240.285	MOTOR UPPER CARTER
112	4517.130	MOTOR BELT PULLEY
113	4514.333	MOTOR BELT PULLEY COUPLING
114	4517.133	FAN BELT PULLEY COUPLING
115	4514.340	FAN BELT PULLEY
116	4240.287	BELT CARTER
117	4514.337	BELT